

TX-FKP65 - Teryx Front Kick Panel

Tools Needed For Installation

Drill with 1/4" Drill Bit
7/16 Open End Wrench
5/32 Allen Wrench
Wire Crimpers / Strippers

Installation Instructions:

SSV
WORKS



Align the kick panel in the corner of the footwell and mark the holes



After marking the holes, drill them using a 1/4" drill bit



Drill a hole through the pod for your speaker wire



Once the holes are drilled, mount the kickpanel using the supplied hardware



After securing all the allen bolts and the 7/16 nuts run your speaker wire into the speaker pod



After attaching the speaker wires to the speaker install the speaker into the SSV Works kick panel.



Install the Grill over the speaker

SSV
WORKS

CORPORATE: SSV WORKS, 19528 VENTURA BLVD. #158 TARZANA, CA 91356
WEB: www.SSVworks.com FAX: 866-293-6751