



SSV WORKS, 4610 Calle Quetzal, Camarillo, CA 93012
www.SSVworks.com | Phone: 818-991-1778 | Fax: 866-293-6751

BR-B65

2021+ Ford Bronco

6.5" Rear Speaker-Pod Add-Ons

WARRANTY INFORMATION:

All SSV Works enclosures are covered by a limited lifetime warranty against defects in material or workmanship. All SSV Works Electronics are covered by a limited 1 year warranty against defects in material or workmanship. All SSV Works Speakers are covered by a limited 1 year warranty against defects in material or workmanship. Labor for replacement of defective components is not covered. Contact SSV Works for further warranty information.

US Patent #D1068720



Please read and understand these instructions completely before installation to avoid possible injury, or damage to the accessory or vehicle.

TOOLS NEEDED FOR INSTALLATION

- #1 Phillips Screwdriver
- T-25 Torx bit
- T-30 Torx bit

PARTS LIST

1. BR-B65U Enclosures (1 pair)	3. Phillips Screw x 2
2. T-25 Torx Screws x 4 (Factory Screws)	4. M6 Screws and Washers x 2

PARTS LIST IMAGES



1. BR-B65-U Enclosures
(1 pair)



2. T-25 Torx Screws x4
(Factory Provided)



3. Phillips Screw x 2



4. M6 Screws and
Washers x 2

DISASSEMBLY



A

A. Remove the two screws securing the top mounting bracket to the factory speaker pod. These are hard to remove with a hardtop we recommend using an angle driver.

Note: These two screws will be re-used for the SSV pods.



B

B. Remove the 3rd screw located at the bottom of the speaker pod bolting the pod to the frame.

INSTALLATION



A

A. Hold the pod up near its mounting location and connect the pod to the factory harness.



B

B. Snap the speaker pod harness cover onto the pod making sure the harness exits the cover through one of the two reliefs.




C

C. Use the provided Philips screw to secure the cover in place.



D

D. Loosely assemble the bottom of the pod to the frame of the vehicle using the provided M6 screw and washer.



E

E. Use the factory screws that were removed in Step A to secure the top of the enclosure.



F

F. Go back and tighten the bottom M6 screw.

G. Repeat these steps on the driver side.